

1 - Ignition/Choke Switch
2 - Emergency Stop Switch
3 - Neutral Start Switch
4 - Tachometer/Accessories Harness Connector
5 - Wiring Harness Connector
6 - Warning Horn
7 - Trim/Tilt Switch